

BENTLEY




nr prod/dł. całkowita/ dł. siedziska




01/110/58
02/115/63




03/168/58
04/178/63
05/192/70
06/208/78




R03/168/58
R04/178/63
R05/192/70
R06/208/78



07/241/63
08/262/70
09/286/78



102



79

111



10L/84/58
11L/89/63
12L/96/70
13L/104/78



10P/84/58
11P/89/63
12P/96/70
13P/104/78



14L/142/58
15L/152/63
16L/166/70
17L/182/78




14P/142/58
15P/152/63
16P/166/70
17P/182/78



18L/215/63
19L/236/70
20L/260/78




18P/215/63
19P/236/70
20P/260/78



55


T1



55

75

T2



75

75

T3



21/58/58
22/63/63
23/70/70
24/78/78



25/116/58
26/126/63
27/140/70
28/156/78



29/189/63
30/210/70
31/234/78



32L/113/58
33L/118/63
34L/125/70
35L/133/78




32P/113/58
33P/118/63
34P/125/70
35P/133/78




36L/171/58
37L/181/63
38L/195/70
39L/211/78




36P/171/58
37P/181/63
38P/195/70
39P/211/78



40L/89/63
41L/104/78




40P/89/63
41P/104/78




111

43



44L/84/58
45L/89/63
46L/96/70
47L/104/78




44P/84/58
45P/89/63
46P/96/70
47P/104/78




BOK NR.2
(26)




BOK NR.3
(27)




12L-43-18P




33L-43-27-46P




34L-43-16P




17L-43-15P



35L-43-24-47P



17L-43-26-41P



17L-41P

Objaśnienie:

zapis np.: 10L(P) / 83 / 58 oznacza:
10L(P) – nr produktu (lewy/prawy)
83 - dł. całkowita w cm
58 – dł. Siedziska w cm
R – funkcja spania